

Magnetic Sensor for Home Door Window Entry Warning Switch



What is Magnetic Reed Switch?

The reed switch is an electrical switch operated by an applied magnetic field. ...

The switch may be actuated by an electromagnetic coil, making a reed relay, or by bringing a permanent magnet near it.

When the magnetic field is removed, the contacts in the reed switch return to their original position.

What are magnetic reed switches used for?

A reed switch is an electromagnetic switch used to control the flow of electricity in a circuit.

They are made from two or more ferrous reeds encased within a small glass tube-like envelope, which become magnetised and move together or separate when a magnetic field is moved towards the switch.

Specifications

Sensing distance:	15-25mm
Shell material:	ABS
color:	White
Electrical parameters:	maximum power 10W
	working voltage 100VDC
	working current 0.5A
Switch type:	NO-Normally Open/NC-Normally Close/NO+NC
Scope of application:	wooden doors and windows
Lead:	L1007UL#24AWG260mm

Dimensions

